

# Be2K-Plus USER Manual

*The information contained in this document is subject to revision and change without notice.*

*No part of this document may be copied or reproduced in any form or by any means without the prior written consent of the Bernini Design Company. Bernini Design assumes no responsibility for any errors that may appear in this instruction manual or in the wiring diagrams. Although Bernini Design has taken all possible steps to ensure that the User Manual is complete, accurate and up-to-date, we accept that errors may occur. If you encounter problems with this instruction manual, please complete this form and send it back to us.*

**FAX Message (+39 0386 31657), From:** \_\_\_\_\_

**Name:** \_\_\_\_\_ **Company:** \_\_\_\_\_ **Tel/Fax:** \_\_\_\_\_

**I would like to report the following error:** \_\_\_\_\_

## Customer Support BERNINI DESIGN SRL ITALY

e-mail: [bernini@bernini-design.com](mailto:bernini@bernini-design.com) mobile: ++40 721 241 361 or ++39 335 7077 148.

## Warranty

Bernini Design SRL (hereinafter "BD") warrants that Be2K-Plus shall be free from failure due to components or manufacturing over a period of 3 years from the BD delivery date. Upon any return by the customer BD shall, at its discretion, either repair or replace the product without charge. BD will then return the Be2K-Plus to the buyer, reset to the factory default settings at no extra charge.

The buyer shall furnish sufficient information on any alleged defects in the product, so as to enable BD to determine their cause and existence. If the Be2K-Plus is not defective, or the product is defective for reason other than that covered by this warranty, then the buyer will be charged accordingly.

Warranty cover will not apply if the Be2K-Plus has been used in contravention of the User Manual or other applicable operating instruction, particularly if such defects are caused by misuse, improper repair attempts or negligence in use or handling. This purchase is non-refundable.

This equipment complies with the EMC protection requirements.



## **!! IMPORTANT WARNINGS !!**

**High voltages are present inside the Be2K-Plus. To avoid the risk of electric-shock, operating personnel must not remove the protective cover. Do not disconnect the Earth (safety ground) connection! The Be2K-Plus can and will start the engine at anytime. Do not work on equipment, which is controlled by the Be2K-Plus without isolating it first. When servicing the engine, always disconnect the battery and battery charger. We recommend that warning signs be placed on equipment indicating the above.**

## Alphabetic Index

<b>Alternator Failure</b> .....	13.04	<b>Manual</b> .....	2.20
<b>Alarms</b> .....	13.00, 5.05	<b>Memory Events</b> .....	5.05
<b>Alarm (Horn)</b> .....	13.00	<b>Oil pressure/Temperature.</b>	13.05
<b>Alarm inputs 1-2- -</b> .....	13.02	<b>OIL T (Temperature)</b> .....	13.05
<b>Automatic</b> .....	2.3	<b>Operating modes</b> .....	2.0
<b>Aux Temperature</b> .....	13.05	<b>Overload</b> .....	13.04
<b>Battery, Alarms</b> .....	13.03	<b>Over Frequency</b> .....	13.04
<b>Belt break</b> .....	13.03	<b>Over Voltage</b> .....	13.04
<b>Can Bus error</b> .....	13.01	<b>Over Speed</b> .....	13.03
<b>Charger Failure</b> .....	13.03	<b>Panel emergency</b> .....	13.02
<b>Contactora</b> .....	2.21	<b>Parameters error</b> .....	13.01
<b>Coolant</b> .....	13.05	<b>Parameters reading</b> .....	11.00
<b>Clock Error</b> .....	13.01	<b>Periodic test</b> .....	7.00
<b>Current Warning</b> .....	13.04	<b>Power &amp; Energy</b> .....	5.03
<b>Current Shutdown</b> .....	13.04	<b>Pressure Switch</b> .....	13.07
<b>Display</b> .....	3.1, 4.0	<b>Pressure Sensor</b> .....	13.07
<b>Display Messages</b> .....	4.0	<b>Pick up Failure</b> .....	13.03
<b>Earth Failure</b> .....	13.04	<b>Pump Timeout</b> .....	13.06
<b>Emergency input</b> .....	13.02	<b>Push buttons</b> .....	1.0
<b>Event history</b> .....	5.06	<b>Remote lock</b> .....	13.02
<b>Fail to Start</b> .....	13.03	<b>Read Parameters</b> .....	12.00
<b>Fail to Stop</b> .....	13.03	<b>Rent</b> .....	13.08
<b>Front Panel</b> .....	1.0 Figure 1	<b>Reverse Power</b> .....	13.04
<b>Frequency</b> .....	13.04	<b>R.P.M (Speed)</b> .....	5.04
<b>Fuel Level</b> .....	13.06	<b>Settings (Parameters)</b> .....	12.00
<b>Fuel Level</b> .....	13.06	<b>Sequence error</b> .....	13.04
<b>Fuel Reserve</b> .....	13.06	<b>Service &amp; Maintenance</b> .....	8.00
<b>Fuel Sensor</b> .....	13.06	<b>Sensor Failure</b> .....	13.05/6/7
<b>Generator Voltage</b> .....	13.04	<b>Short circuit</b> .....	13.04
<b>Generator Frequency</b> .....	13.04	<b>Start &amp; Stop</b> .....	2.20
<b>Generator Failure</b> .....	13.04	<b>Stop &amp; Start</b> .....	2.20
<b>Hour Counter</b> .....	5.04	<b>Starting Failure</b> .....	13.03
<b>High Fuel</b> .....	13.06	<b>Tank Empty</b> .....	13.06
<b>Inputs 1-2-3-4-5</b> .....	13.02	<b>Temperature Switch</b> .....	13.05
<b>Kva alarm</b> .....	13.04	<b>Temperature Sensor</b> .....	13.05
<b>KG-KM</b> .....	13.04	<b>Test (periodic)</b> .....	7.00
<b>LED, LEDs</b> .....	3.0	<b>Test mode</b> .....	2.40
<b>Lamp Test</b> .....	3.0	<b>Under Voltage</b> .....	13.04
<b>Low Fuel</b> .....	13.06	<b>Under Frequency</b> .....	13.04
<b>Low Oil Pressure</b> .....	13.07	<b>Under Speed</b> .....	13.03
<b>Low Battery voltage</b> .....	13.03	<b>Voltage measurements</b> .....	5.01, 5.02
<b>Measurements</b> .....	5.0		
<b>Maintenance Timers</b> .....	8.0, 13.08		
<b>Memory error</b> .....	13.01		

# Be2K-Plus User's Manual - Contents

## Quickstart guide ! How to.....

<i>How to.....</i>	<i>See section..</i>	<i>How to.....</i>	<i>See section..</i>
start the engine	2.20, 2.30	cancel an alarm	13.00
stop the engine	2.20, 2.30	set the clock	6.00
cancel alarm	13.00	use the display	4.00
select a mode of operation	2.0	read parameters	12.00
display Voltage & Current	3.01	ask for support	15.00

For issues not included in the above list, we recommend that you consult the Alphabetical index (page 2)

- 1.0 Introduction..... page 4**
- 2.00 Selecting an operational Mode..... page 4**
  - 2.10 OFF mode ..... page 5
  - 2.20 MANUAL mode ..... page 5
  - 2.21 MANUAL control of the LOAD..... page 5
  - 2.30 AUTO mode ..... page 6
  - 2.40 TEST mode ..... page 6
- 3.0 LEDs indicators ..... page 6**
- 3.01 LED Display description ..... page 7**
- 4.0 Main Menu List..... page 7**
- 5.0 Measurements & Events ..... page 7**
  - 5.01 Generating Set ..... page 7
  - 5.02 Mains Monitoring ..... page 8
  - 5.03 Power & Energy ..... page 8
  - 5.04 Engine & Fuel..... page 8
  - 5.05 Alarm Status..... page 9
  - 5.06 Event History..... page 9
- 6.0 Clock Settings..... page 10**
- 7.0 Test & Rental Settings ..... page 10**
- 8.0 Maintenance Timers ..... page 11**
- 9.0 Programming & Password..... page 11**
- 11.0 Display & Languages ..... page 12**
- 12.0 Read Parameters ..... page 12**
- 13.0 Alarms, Warnings & Shutdowns ..... page 13**
  - 13.01 Clock & Periodic test alarm..... page 13
  - 13.02 Emergency alarm & Shutdowns..... page 14
  - 13.03 Miscellaneous Engine Alarms..... page 14
  - 13.04 Alternator & Contactors Alarms..... page 15
  - 13.05 Temperature Alarms ..... page 15
  - 13.06 Fuel Level Alarms..... page 16
  - 13.07 Oil Pressure Alarms..... page 16
  - 13.08 Service and Rental Contract Alarms ..... page 16
  - 13.09 TELECOM equipment Alarms ..... page 17
- 14.0 Panel builder notes ..... page 17**
- 15.0 Support & Help..... page 17**


### Please work with us

Our policy is to support our customers. We have endeavoured to make this user manual friendly and simple to use. If you have any proposals for improving the quality of the document, or to modify the equipment in order for it to respond better to yours or your customer requirements, please contact us at: [support@bernini-design.com](mailto:support@bernini-design.com)

### Section: 1.0 Introduction


The Be2K-Plus integrates a 3-Phase Automatic Mains Failure module and a Generating Set controller. The Be2K-Plus provides visual indication by means of LEDs and Displays for Engine environment, Electrical parameters and Alarms. The Be2K-Plus is pre-programmed by your Panel or Genset manufacturer. Figure 1 illustrates the layout of the front panel.

Figure 1: Front Panel layout



### Section 2.0: Selecting an Operational Mode

The mode of operation is selected by pushbuttons and indicated by means of green LEDs:




**2.10 OFF mode**

This mode clears the fault alarms (see section 13.00) and allows the parameters to be read (see section 12.0). The display indicates the MAIN MENU LIST (see section 4.00). The Display and LEDs are turned off after 30 seconds without a button press operation and a dot on the display will blink slowly. Press one of the pushbuttons on the front panel to return to the display.


**2.20 MANUAL mode**

The MANUAL mode allows you to manually control the Engine and LOAD (see 2.21). Follow the instructions:

	<p><b>In case of presence of alarms, consult section 13.00 first</b></p> <p>Push the [MAN] pushbutton to select the MANUAL mode. Push the [START] pushbutton until the engine starts; the display will automatically open a page with information about the start sequence: Preglow, Starting..... (see section 5.04)</p> <p>When the engine is running, the green LED 'ENGINE RUNNING' turns on. To stop the engine, push the [STOP] pushbutton until the [STOP] message appears on the display. If the engine has already stopped, it is possible to reset the STOP sequence by pressing the [STOP] pushbutton.</p>
---	---

**2.21 Manual Control of the LOAD**

To control the contactors manually, follow the instructions:

	<p><b>Instructions</b></p> <p>Select the MANUAL mode, start the engine (see 2.20) and wait until the green LED 'Generator Presence' turns on. Push the [ KG ] pushbutton to close the contactor of the Generator. To transfer the Load to the Mains, wait for the green LED Mains Presence and push the [ KM ] pushbutton: the KG will open and KM will close after a 2-seconds delay. The displays (section 3.01 &amp; 5.00) indicate all parameters.</p> <p><b><u>To switch off the LOAD, push the [ O ] pushbutton at anytime.</u></b></p>
---	---



**!! WARNING !!**

**LINE VOLTAGE IS EXPOSED WITHIN THE BE2K-PLUS, THE LOAD OR ANCILLARY CIRCUITRY EVEN WHEN THE GREEN LEDs ARE TOTALLY OFF**

**2.30 AUTO mode**

**!! WARNING !!**

The Be2K-Plus can start the engine at anytime without warning. Do not work on equipment, which is under the live control of the Be2K-Plus. When servicing the engine, disconnect the battery, the battery charger and all sources of Voltage and Current. We recommend that warning signs be placed on equipment indicating the above.

If alarms are already displayed, consult section 13.00 first

Push the [AUTO] pushbutton until the green LED illuminates. The engine will start in the case of a pre-existing Mains failure. After the warm-up time and if the Voltage and Frequency are within the correct settings, the contactor of the GENERATOR will close to supply your LOAD. The displays (section 3.01 & 5.00) indicate all parameters. If the Mains restores, the KG will open. The KM will then close following the pre-programmed changeover timing. The Engine will stop after an idling cooling down time. If the engine shuts down, the KM can close independently of the Mains status depending on the setting of Be2k-Plus, otherwise the KM will close only if the parameters of the Mains are within the programmed settings. In AUTO mode, the Be2K-Plus will periodically test the engine if the parameters PERIODIC TEST are correctly programmed (section 7.01). During the PERIODIC TEST, the green LED of the AUTO mode will continue to blink. In AUTO mode, the Be2K-Plus can start and stop the engine if a remote control is activated. You can stop the engine at anytime by selecting the MAN mode.

(\*)SEE NOTE





**2.40 TEST mode**

Push and hold the [AUTO] pushbutton until the green LED starts to blink. The Be2K-Plus will start the engine and transfer the LOAD to the generator only in the case of Mains Failure (if not otherwise programmed by your Panel supplier). To exit the TEST, push the [AUTO] pushbutton shortly or select another mode of operation.

(\*)NOTE: If you push the [STOP] pushbutton when the Be2K-Plus is in AUTO or TEST, the 'PANEL EMERGENCY' alarm will energize (see section 13.02).

**Section: 3.00 LEDs indicators**

The table explains the function of the LEDs (solid state lamps) on the front panel (see section 1, Figure 1). To test the LEDs, push the [OFF] pushbutton to enter the OFF MODE. Push and hold the [←] and [→] pushbuttons simultaneously or push the external TEST LAMP pushbutton (if provided by your panel manufacturer).

LED(s)	Note	LED(s)	Note
Indicators of Voltages and Contactor status. See section 2.21.  (Vac, KM, KG....)	4 Leds (Green color). See section 2.21 for the description.	Manual Mode 	Green LED: it turns on indicating the MANUAL mode
	4 Led indicators (red) for: -Oil pressure shutdown -Temperature shutdown -No Fuel shutdown -Generator shutdown	Auto Mode 	Green LED: it turns on indicating the AUTO Mode. It will blink in TEST Mode.
 RED YELLOW	<b>Red Led indicator:</b> it turns on in event of a shutdown. <b>Yellow Led indicator:</b> it turns on in case of a warning. The Graphic display will indicate all details of the alarm(s).	Engine Running (see Fig.1)	Green LED on the drawing of the engine: it turns on when the engine is running.
		Current Mode & Voltage Mode (see section1, Fig.1)	2 yellow LEDs indicate the display mode (Voltage or Current). Push [ACK-F1] to toggle the display indication.

### Section 3.01 LED DISPLAY description

The red LEDs Display consists of 3 groups of 4 digits. The display on the **TOP** indicates the electrical parameters of Phase L1, the display on the **MIDDLE** the Phase L2 and the display on the **BOTTOM**, the Phase L3. Two yellow LEDs indicate the mode of the display (Voltage Mode or Current Mode). Push the **[ACK-F1]** button to toggle the display mode; the other yellow LED will illuminate. See figure 1 in section 1.00. The display indicates the parameters of the Generator only.

### Section 4.00 Main Menu List

Push the [OFF] to select the OFF mode and push [←]; the following Main Menu will appear:

MAIN MENU LIST	Section	Use [↑] or [↓] to select a Menu and [→] to enter the Menu
<b>MEASUREMENTS &amp; EVENTS</b>	5.00	Accesses various Measurements and Events
<b>CLOCK SETTINGS</b>	6.00	Allows you to set the Clock
<b>TEST &amp; RENTAL</b>	7.00	Miscellaneous functions and Automatic Test
<b>MAINTENANCE TIMERS</b>	8.00	Shows the status of the Maintenance timers
<b>READ PARAMETERS</b>	12.00	All parameters and settings can be read
<b>COMMUNICATIONS</b>	10.00	Used to broadcast alarms and information
<b>DISPLAY &amp; LANGUAGE</b>	11.00	Display settings and language selection
<b>PROGRAM PARAMETERS</b>	9.00	Function reserved to the Panel Builder. Consult your supplier for details
<b>CLEAR MEMORY</b>		
<b>CLEAR EVENTS</b>		
<b>CLEAR ENERGY COUNTER</b>		
<b>CLEAR N° OF STARTS</b>		
<b>USER PASSWORD</b>		
<b>OEM PASSWORD</b>		

The **MAIN MENU LIST** appears in the OFF mode (see 2.10). After 30 seconds without operating the [↑][↓][←][→] pushbuttons, the Display will shut down. To turn on the display push any of the button on the front panel.

### Section 5.00: MEASUREMENTS & EVENTS

Use [F4↑] or [F5↓] to select this Menu from the **MAIN MENU LIST** (section 4.0) and push [→]. The submenu includes the indications of all parameters of the Engine and Generator.

Display Indication	See Section...	Note
<b>GENERATING SET</b>	5.01	
<b>MAINS MONITORING</b>	5.02	Use [F4↑] or [F5↓] to select a sub-menu and [→] to enter the submenu. Push [←] to return back.
<b>POWER &amp; ENERGY</b>	5.03	
<b>ENGINE &amp; FUEL</b>	5.04	
<b>ALARM STATUS</b>	5.05	
<b>EVENT HISTORY</b>	5.06	
<b>CALIBRATION</b>	Function reserved to the Panel Builder	
<b>ABOUT BE2K-PLUS</b>	Provides miscellaneous information about the controller: - Software Version and Release - Engine Manufacturer & Model	

#### Section 5.01 GENERATING SET

This Sub-menu indicates the following measurements:

Use [↑] or [↓] to select a page, use [←] to return					
L1-L2 (V) [XXX]	CURRENT 1 [XXXX]	L1-N (V) [XXX]	FREQUENCY [XX.X]	SEQUENCE [CW/CCW]	
L2-L3 (V) [XXX]	CURRENT 2 [XXXX]	L2-N (V) [XXX]	CONTACTOR [ON/OFF]	EARTH FAULT [X.XX]	
L1-L3 (V) [XXX]	CURRENT 3 [XXXX]	L3-N (V) [XXX]	SIMULATED [ON/OFF]		

**Section 5.02 MAINS MONITORING**

This Sub-menu indicates the following measurements:

Use [↑] or [↓] to select a page, use [←] to return			
R - S (V) [XXX]	R - N (V) [XXX]	FREQUENCY [XX.X]	
S - T (V) [XXX]	S - N (V) [XXX]	SEQUENCE [CW/CCW]	
T - R (V) [XXX]	T - N (V) [XXX]	CONTACTOR [ON/OFF]	
		SIMULATED [ON/OFF]	
		TELECOM VDC [XX.X]	

**Section 5.03 POWER & ENERGY**

This Sub-menu indicates the following measurements:

Use [↑] or [↓] to select a page, use [←] to return			
KVA 1 [XXXX]	KVAR 1 [XXXX]	KW 1 [XXXX]	
KVA 2 [XXXX]	KVAR 2 [XXXX]	KW 2 [XXXX]	
KVA 3 [XXXX]	KVAR 3 [XXXX]	KW 3 [XXXX]	
PF 1 [X.XX]	TOTAL KW [XXXX]	PF TOTAL [X.XX]	
PF 2 [X.XX]	TOTAL KVA [XXXX]	ENERGY KWH [XXXXXXXXX]	
PF 3 [X.XX]	TOTAL KVAR [XXXX]		

**Section 5.04 ENGINE & FUEL**

ENGINE STATUS PAGE				
push the [↓] to browse all the other pages related to the engine				
<b>ENGINE STATUS</b>  [MESSAGE 1] [MESSAGE 2]  COUNTING [XXXX]  DATE [XX.XX] TIME [XX:XX] HOUR RUN [XXXXXXXXX]	This page can indicate two messages that describe the status of the engine and the status of the active timer (COUNTING). Possible messages are:			
	RUNNING		NOT RUNNING	RUNNING ON LOAD
	REST	PRELUBE	STARTING	CRANKING
	STOPPING		COOLING	WARM UP
	IDLE SPEED		PREGLOW	PERIODIC TEST
	MAINS BREAKER DELAY		MAINS FAILURE DELAY	REMOTE TEST
	MAINS RESTORE DELAY		TELECOM INHIBIT	
	The engine run hours and Date / Time are also indicated			

push the [↓] to browse all the other pages related to the engine

Use [↑] or [↓] to select a page, use [←] to return			
SPEED RPM [XXXX]	FUEL LEVEL [XX]	RENTAL H (!) [XXXXX]	
OIL PRESSURE [XX.X]	TRANSFER PUMP [ON-OFF]	MAINTEN. 1 (!) [XXXXX]	
COOLANT °C [XXX]	V BATTERY [XX.X]	MAINTEN. 2 (!) [XXXXX]	
	ALTERNATOR V [XX.X]	MAINTEN. 3 (!) [XXXXX]	
	N° / STARTS [XXXXXXXX]		

(!) This indicates the remaining hours before expiry of the Maintenance Timers and Rental contract (see sections 7.01 & 8.0)



If your engine is equipped with an Electronic Control Unit, additional pages will appear as indicated below. The indication may change according to the model of engine (consult your supplier or the user manual of the engine for further details) :

Use [↑] or [↓] to select a page, use [←] to return			
OIL °C [XXX]	OIL °C [XXX] SPN 175	WATER IN FUEL[ON/OFF] SPN 97	FUEL RATE [XXX] SPN 183
AUXILIARY °C [XXX]	OIL LEVEL [XX.X] SPN 98	FUEL °C [XXX] SPN 174	PEDAL % [XXXX] SPN 91
	OIL PRESSURE [XX.X] SPN 100	FUEL BAR [XXX] SPN 94	TURBO BAR [XX.X] SPN 102

Use [↑] or [↓] to select a page, use [←] to return			
EXSAUST °C [XXXX] SPN 173	COOLANT °C [XXX] SPN 110	CRANKCASE BAR [XXXX] SPN 101	DEMANDE TORQUE [XXXX] SPN 153
BAROMETRIC P [XXXX] SPN108	COOLANT % [XX.X] SPN 111	BOOST °C [XXXX] SPN 105	ACTUAL TORQUE [XXXX] SPN 513
	COOLANT BAR [XXXX] SPN 109	INTAKE BAR [XXXX] SPN 106	LOAD [XXXX] SPN 92

**Section 5.05 ALARM STATUS**

This Sub-menu indicates the active alarms together with real time clock indication and general alarm information. A typical alarm screen is as follows (see section 13.00 for the list of the alarms):

Use [↑] or [↓] to browse the content of the pages	
ALARMS PAGE 1 OF 10 OIL PRESSURE WARNING 0,8 BAR DD:MM:YY HH:MM:SS	This page opens automatically in the case of alarm(s). The Alarm status is also recorded in the Memory Events register. To return to the MEASUREMENTS pages, push the [←] pushbutton.

In case of alarms detected from an Electronically Controlled engine, the Be2K-Plus will provide additional information. Consult the user manual of the engine manufacturer for further details.

ALARMS PAGE 1 OF 10 [DESCRIPTION OF ALARM] SPN XX FM1XX DD:MM:YY HH:MM:SS	This page opens automatically in the case of alarm(s). The Alarm status is also recorded in the Memory Events register. To return to the MEASUREMENTS pages, push the [←] pushbutton.
--	---

**Section 5.06 EVENT HISTORY**

This submenu displays the last 200 events providing Date & Time information. The Events History captures: Warnings, Shutdowns, switching of the Contactors, Start & Stop sequences and changing of Operating Modes. The display can indicates 70 pages (3 alarms for each page)

Use [↑] or [↓] to browse the content of the pages	
EVENT HISTORY 1 / 70 EMERGENCY DD:MM:YY HH:MM:SS	Push [↑] or [↓] to browse the list of the events. To return to MEASUREMENTS, push the [←] pushbutton. (see section 13.0 for the list of the alarms)

### Section 6.00: Clock Settings

Use [↑] or [↓] to select this Menu from the **MAIN MENU LIST** (section 4.0) and push [→] to enter the menu.

Display Indication	Section	Note
<b>CLOCK DAY</b> 1	Use [↑] or [↓] to select a function. Push [→] to enter the numerical field. Push [↑] or [↓] to set a value. Push [←] to return to the function. After setting the clock, push [↓] to select the [PUSH F3 TO SET CLOCK] function (see below) in order to start the clock.	
<b>CLOCK MONTH</b> 1		
<b>CLOCK YEAR</b> 2000		
<b>CLOCK HOUR</b> 0		
<b>CLOCK MINUTE</b> 0		
<b>DATE FORMAT DD:MM:YY</b>	Select the function, push [→] and [↑] or [↓] to select the option MM:DD:YY (MONTH:DAY:YEAR) instead of DD:MM:YY (DAY:MONTH:YEAR).	
<b>PUSH F3 TO SET CLOCK</b>	Select this functions and push [→] to start up the Be2k-Plus clock at the proper moment (use an external clock reference)	

### Section 7.00: Test & Rental Program

#### 7.01: Periodic Test Settings

Use [↑] or [↓] to select this Menu from the MAIN MENU list (section 4.0) and push [→] to enter the menu.

Display Indication	Description
<b>TEST DAY</b> 1	<b>Automatic test setting.</b> You can set the date of the Periodic Test. The engine will run for the [TEST DURATION] time. The Be2k-Plus will repeat the test every [REPEAT RATE] days. After a test, the <b>DATE</b> is automatically updated to inform you about the date of the next TEST attempt. In order to program correctly, make sure not to set the scheduled date at a time that has already occurred. <b>Instructions:</b> Use [↑] or [↓] to select a function. Push [→] to enter the numerical field. Push [↑] or [↓] to set a value. Push [←] to return to the function. After setting date and time, push [↓] to select the TEST DURATION.
<b>TEST MONTH</b> 1	
<b>TEST YEAR</b> 2008	
<b>TEST HOUR</b> 0	
<b>TEST MINUTE</b> 1	
<b>TEST DURATION</b> OFF	Duration of the test (1-60 minutes, or OFF to disable the TEST).
<b>TEST REPEAT</b> OFF	Repetition rate of the test (1-60 days, or OFF to disable the TEST). Push [←] to return to the function. The Be2k-Plus will start to count-up the time.
<b>RENTAL CONTRACT</b> OFF	It indicates the hours of your Rental contract. The remaining time is indicated in the ENGINE & FUEL menu (see 5.04)
<b>EJP</b> 5"	(Effacement des Jours de Pointe).
<b>KG TEST CONTROL</b> OFF	These functions are reserved to the Panel Manufacturer.
<b>RUN TIMEOUT</b> OFF	
<b>2XGEN. + MAINS</b> OFF	
<b>LOW BATT. START</b> OFF	
<b>HIGH BATT. STOP</b> OFF	
<b>H AUX °C START</b> OFF	
<b>L AUX °C STOP</b> OFF	
<b>TELECOM BATT.</b> OFF	
<b>TELECOM °C</b> OFF	
<b>TELECOM V LOW</b> OFF	
<b>TELECOM V HIGH</b> OFF	
<b>TELECOM °C LOW</b> OFF	
<b>TELECOM °C HIGH</b> OFF	

### **Section 8.0: Maintenance Timers**

Use [↑] or [↓] to select this Menu from the MAIN MENU list (section 4.00) and push [→] to enter the menu. These functions are password protected.

Display Indication	Section	Note
<b>MAINTENANCE 1 OFF</b> <b>MAINTENANCE 2 OFF</b> <b>MAINTENANCE 3 OFF</b>		MAINTENANCE 1(2)(3) indicates the setting of the SCHEDULED Maintenance. The remaining time is indicated in the ENGINE PAGE (see section 5.04). <b>Note:</b> when a timer expires, the MAINTENANCE alarm triggers (see section 13.08). Consult your Genset supplier or the Engine user manual in order to carry out the scheduled MAINTENANCE.

### **Section 9.0: Programming & Password**

The programming of the controller is reserved to the Panel or Genset Manufacturer. The programming instructions are indicated in the OEM user manual and are Password protected. Consult your supplier for further details. You are allowed to set a User password in order to restrict the access for the following functions:

- TEST & RENTAL PROGRAM
- MAINTENANCE TIMERS
- COMMUNICATIONS

User or Oem password selection:

Display Indication	Note
<b>USER PASSWORD</b>	Use [↑] or [↓] to select a function and push [→] to enter the function; the following screen will appear (see below)

User password programming:

Display Indication	Note
<b>ENTER USER PASSWORD</b> <b>CANCEL - - - - OK</b> <b>SELECT OK TO CONFIRM</b>	A) - Use [←] or [→] to select a digit of the password. B) - Push [↑] or [↓] to edit the digit (Number or Upper case letter). C) - Repeat steps A) and B) in order to edit the 4-digit password. D) - Select OK using the [→] button (the OK highlights when selected). E) - Push the [→] button to confirm the password. If the password is correct, the message [PASSWORD OK] will be displayed

User password available options:

Display Indication	Note
<b>CHANGE USER PASSWORD</b> <b>CLEAR USER PASSWORD</b>	Once you've entered the correct password, the Be2k-Plus presents the options to change or to clear the USER password. A) - Push [↑] or [↓] to select the function B) - Push [→] to enter the function C) - Follow menu-driven instructions to complete the task

### **Section 10.0: COMMUNICATIONS**

Use [↑] or [↓] to select this Menu from the MAIN MENU list (section 4.0) and push [→] to enter the menu. Additional information is described in the BE-2KPLUS communication User Manual if provided by your supplier.

Display Indication	Section
<b>RS485 NODE 1</b> <b>MODEM SETTINGS</b> <b>TCP/IP SETTTINGS</b>	These functions are reserved to the Panel Manufacturer.

### **Section 11.0: Display & Language**

Use [↑] or [↓] to select this Menu from the MAIN MENU list (section 4.00) and push [→] to enter the menu.

Display	Instructions
<b>LANGUAGE</b>	A) - Use [→] button to enter the selection of the language. Choose the language using the [↑] / [↓] pushbuttons B) - Push the [←] twice; the display will indicate the 3 options:  - EXIT by pushing [←] - SAVE (the selection of the language) by pushing [ACK-F1] - RETURN BACK (to selection language) by pushing [→]  Languages available are ENGLISH-ITALIAN-FRENCH-GREEK-SPANISH-RUSSIAN
<b>CONTRAST 25%</b>	You can optimize the text-readability of the display: - Push the [→] button to enter the selection, and [↑] or [↓] to choose 25%, 50% or 100% - Push [←] to return BACK.

### **Section 12.0: Read Parameters**

To read the parameters, follow the instructions:

( 1 ) – Push the [OFF] button to enter the OFF mode; push [←]

( 2 ) – Select, from the MAIN MENU LIST (see section 4.0), the function [READ PARAMETERS]; push [→] The PARAMETERS MENU will appear on the screen of the display (see below).


( 3 ) – Choose one Menu from the **PARAMETERS MENU** list by using the [↑] or [↓] buttons and push [→] to enter the Menu. Push [↑] or [↓] to browse the parameters. Push [←] to return. You have no access to the programming of the parameters (consult your panel manufacturer).

PARAMETERS MENU	PARAMETERS MENU
<b>MAINS PARAMETERS</b> GENERATOR PARAMETERS ENGINE PARAMETERS SPEED PARAMETERS FUEL SETTINGS MISCELLANEOUS AUXILIARY °C INPUT OIL °C INPUT	OIL PRESSURE INPUT COOLANT °C INPUT FUEL LEVEL INPUT CONFIGURABLE INPUTS CONFIGURABLE OUTPUTS CAN BUS SETTINGS

### **Section 13.0: Alarms, Warnings and Shutdowns**

The Be2K-Plus features:

**A)** - A yellow LED that turns on in case of a warning, a red LED that turns on in case of a shut down and a pushbutton to silence the Horn (**[ACK-F1]**) as indicated below:



- B)** - Symbols with red LED, on the front panel, indicating the alarms of the engine (see figure 1, section 1.0)
- C)** - Display messages describing all alarms including Date, Time and Measurements (see examples in section 5.05).
- D)** - Event history capable of recording 200 alarms and events (see section 5.06)

#### **Instructions in case of Alarms:**

- 1) Look at the front fascia and take note of RED indicators and MESSAGES indicated on the display.
- 2) Some alarms shut down the engine after a programmable delay in order to cool down the engine. We recommend that you wait for the complete stop of the engine
- 3) Push the **[ACK-F1]** pushbutton in order to acknowledge the alarm. Push the **[OFF]** button
- 4) Consult the following sections for further information and if in doubt ask for support of your supplier
- 5) Remove the cause of the alarm
- 6) Restart the engine (see section 2.0)

**!!! WARNING !!! Always consult your supplier or the user manual of the engine. A short description of the alarm follows below. Recommendations for solving the problem are also indicated.**

Displayed messages	Description	LED
<b>13.01 - Clock and Periodic Test Alarms</b>		
<b>CLOCK ERROR</b>	Real time clock failure or wrong programming <b>(Re-program the clock, see section 6.00)</b>	Yellow
<b>AUTOMATIC TEST FAILED</b>	Automatic Periodic Test Fault or wrong programming. <b>(Re-program the periodic test, section 7.01)</b>	
<b>PARAMETER ERROR</b> <b>MEMORY ERROR</b>	Error in a parameter or Failure of the memory In order to clear the alarm, follow the instructions: <b>( A )</b> – Disconnect the power supply for a minute (a switch is provided) <b>( B )</b> – Reconnect the power supply. If the message disappears you can continue using the controller without problem. If the error persists, consult your supplier. Assistance will be required.	
<b>CAN BUS ERROR</b>	Failure of the CAN-BUS communication <b>( !!! )</b>	

**( !!! ) : CONSULT YOUR SUPPLIER IMMEDIATELY**




<b>13.02 - Emergency Alarms &amp; Shutdowns</b>		<b>LED</b>
<b>FRONT PANEL EMERGENCY</b>	This alarm takes place if you push the [STOP] button when the Be2k-Plus is in AUTO mode ( <b>cancel the alarm, see 13.00</b> )	Red
<b>ALARM 1 SHUTDOWN</b>	<p>ALARM 1 and 2 stops the engine</p> <p style="text-align: center;"><b>NOTE (^)</b></p> <p style="text-align: center;">Programmable Input 1 (2,3,4 or 5) can provide Warning (audible and optical) or it can stop the engine.</p> <p style="text-align: center;"><b>NOTE (^)</b></p>	Red
<b>ALARM 2 SHUTDOWN</b>		
<b>INPUT 1 WARNING</b>		Red or Yellow
<b>INPUT 1 SHUTDOWN</b>		
<b>INPUT 2 WARNING</b>		
<b>INPUT 2 SHUTDOWN</b>		
<b>INPUT 3 WARNING</b>		
<b>INPUT 3 SHUTDOWN</b>		
<b>INPUT 4 WARNING</b>		
<b>INPUT 4 SHUTDOWN</b>		
<b>INPUT 5 WARNING</b>		
<b>INPUT 5 SHUTDOWN</b>		
<b>REMOTE LOCK</b>	Indication of Remote Lock because a remote switch holds the system inoperative, <b>NOTE (^)</b>	Red

**NOTE (^) Remove the cause of the alarm, cancel the alarm and restart the engine**


<b>13.03 - Miscellaneous Engine Alarms</b>		<b>LED Indicator</b>
<b>PICK UP FAILURE</b>	Pick Up Failure shutdown (!!!!)	Red
<b>OVER SPEED SHUTDOWN [X- - X]</b>	Over Speed shutdown	
<b>UNDER SPEED SHUTDOWN [X- - X]</b>	Under Speed shutdown	
<b>HIGH BATTERY WARNING</b>	High Battery Voltage warning: 11,8/15V for 12V battery and 23,6/30V for 24V battery ( <b>the battery requires maintenance</b> )	Yellow
<b>LOW BATTERY WARNING</b>		
<b>FAIL TO START</b>	Starting Failure shutdown <b>NOTE (^)</b>	Red
<b>FAIL TO STOP</b>	Fail to stop shutdown (!!!!)	
<b>ENGINE BELT BREAK</b>	Engine Belt break shutdown or Charger Failure (!!!!)	

[X- - X] Note: the display records the value of the measurement in the moment the parameter triggers the alarm.

**(!!!!): CONSULT YOUR SUPPLIER IMMEDIATELY**


13.04 - Alternator and Contactors Alarms			LED Indicator	
OVERLOAD SHUTDOWN	Overload alarm	<p><b><i>(These alarms trigger when the Load connected to the Generator causes the alternator to attempt to work outside it's limits. Cancel the alarm and restart. If the problem persists consult your supplier or an electrician)</i></b></p>		
SHORT CIRCUIT [X- - X]	Short circuit alarm			
UNDER VOLTAGE [X- - X]	Under Voltage alarm			
OVER VOLTAGE [X- - X]	Over Voltage alarm			
PHASE UMBALANCE [X- - X]	Phase unbalance shutdown			
UNDER FREQUENCY [X- - X]	Under Frequency alarm			
OVER FREQUENCY [X- - X]	Over Frequency alarm			
OVER KVA SHUTDOWN [X- - X]	Over Apparent Power alarm			
PHASE SEQUENCE ERROR	Phase Sequence alarm			
OVER CURRENT WARNING [X- - X]	Over Current alarm			 Yellow
OVER CURRENT SHUTDOWN [X- - X]				
ALTERNATOR FAIL	Alternator Failure alarm			
EARTH FAILURE	Earth Failure alarm			
REVERSE POWER [X- - X]	Reverse Power alarm			
KM FAILURE	The Mains or Generator contactor failed to operate <b>(!!!!)</b>	Yellow		
KG FAILURE				

**(!!!!): CONSULT YOUR SUPPLIER IMMEDIATELY**

13.05 - Temperature Alarms			LED	
TEMPERATURE SWITCH	High Engine Temperature	<p><b><i>(These alarms trigger in the case of High Temperature. Cancel the alarm and wait for a natural cooling of the affected condition. Identify and then rectify the cause of the over temperature. If the problem persists consult your supplier)</i></b></p>		
LOW COOLANT WARNING [X- -X]	Abnormal Temperature of the COOLANT of the engine.			Yellow
HIGH COOLANT WARNING [X- -X]				
COOLANT °C SHUTDOWN [X- -X]				
OIL °C WARNING [X- - X]	Abnormal OIL Temperature; Warning and / or Shutdown.			Red
OIL °C SHUTDOWN [X- - X]				
AUX °C WARNING [X- - X]	Abnormal Auxiliary Temperature (Room temperature for example); Warning and / or Shutdown.			Yellow
AUX °C SENDER SHUTDOWN [X- - X]				
COOLANT SENDER OPEN	Indicates a failure of the temperature sensor used for measurement of this Temperature <b>(!!!!)</b> .			Yellow
OIL °C SENDER OPEN				
AUX °C SENDER OPEN				


[X- - X] Note: the display records the value of the measurement in the moment the parameter triggers the alarm.

**(!!!!): CONSULT YOUR SUPPLIER IMMEDIATELY**

13.06 - Fuel Level Alarms		Led
LOW FUEL WARNING [X- - X ]	Low Level Fuel warning	Yellow
HIGH FUEL WARNING [X- - X ]	High Level Fuel warning	
FUEL RESERVE SENDER FUEL RESERVE SWITCH	Fuel Reserve warning	
TANK EMPTY SENDER TANK EMPTY SWITCH	Be2k-Plus shuts down the engine if the level drops below the limit for the programmed time or if the Reserve Switch remains closed for more than the programmed time.	
PUMP TIMEOUT WARNING	This warning energizes if the PUMP to fill the tank remains activated for more than the programmed time.	
FUEL SENDER OPEN	Failure of the Fuel Sensor. <b>(!!!!)</b>	Yellow

*(These alarms trigger in case of problems regarding Fuel. Verify the status of the tank and consult the user manual of the engine. Cancel the alarm and restart the engine. If the problem persists consult your supplier)*

[X- - X ] Note: the display records the value of the measurement at the moment the parameter triggers the alarm.

13.07 - Oil Pressure Alarms		
LOW OIL BAR WARNING [X- - X ]	Low Oil Pressure Warning	Yellow
LOW OIL BAR SHUTDOWN [X- - X ]	Low Oil Pressure Shut down	
LOW OIL JF9 SHUTDOWN	Low Oil Pressure Shut down (Pressure Switch )	
PRESSURE SENDER OPEN	Failure of the Oil Pressure sensor or failure of the Transmitter of the Oil pressure <b>(!!!!)</b>	Yellow

*(These alarms trigger in the case of lubrication problems. Cancel the alarm, Verify the cause of the fault and consult the user manual of the engine. If the problem persists consult your supplier)*

**(!!!!): CONSULT YOUR SUPPLIER IMMEDIATELY**

13.08 - Service and Rental Contract alarms		LED
MAINTENANCE TIMER 1	<i>These alarms indicate that you are required to perform scheduled Maintenance on the engine (consult your Genset supplier or the Engine manufacturer's user manual). The MAINTENANCE 3 alarm shuts down the engine.</i>	Yellow
MAINTENANCE TIMER 2		
MAINTENANCE TIMER 3		
RENTAL WARNING	This informs you that the Rental contract is about to expire (<48h).	Yellow
RENTAL EXPIRED	Rental period termination. The engine shuts down.	Red
MAX RUN TIME	Timer 'RUN Timeout' expiry. This timer allows the generator to run in AUTO or TEST mode for a limited time. Ask your supplier for the setting. If this alarm takes place, verify the general status of the engine (Fuel level & Oil according to the Engine User Manual), cancel the alarm (section 13.0) and restart the engine.	Red



<b>13.09 - Telecom alarms (Room ambient temperature e Battery voltage of the TELECOM equipment)</b>		
<b>TELECOM °C LOW</b>	These alarms allow you to monitor the Room Temperature and voltage of the TELECOM equipment.	Yellow
<b>TELECOM °C HIGH</b>		
<b>TELECOM V HIGH</b>	Consult your supplier for further details	
<b>TELECOM V LOW</b>		

**14.00 - Panel or Gen-set Builders Notes**

---

---

---

---

---

---

---

---

---

---

**15.0 - SUPPORT**

For help/advice regarding any problem in the use of the Be2k-Plus controller, email:

[bernini@bernini-design.com](mailto:bernini@bernini-design.com)

24h/24h service world wide: +40-721 241 361 or +39 335 7077148